

# Door Sweeps

## INSTALLATION INSTRUCTIONS

- 1 Measure and cut sweep to fit.
- 2 Close door. Hold sweep making gentle contact with the threshold.
- 3 Mark screw holes. Drill holes using #31 or 3.048mm drill bit.
- 4 Install with screws provided.
- 5 Adjust sweep position to make proper contact with the threshold, allowing smooth operation of the door.



[allegion.com.au](http://allegion.com.au)

[allegion.co.nz](http://allegion.co.nz)

ANZ v. 9/16

